

Primo®

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ USE MANUAL



ΗΛΕΚΤΡΙΚΗ ΚΟΥΒΕΡΤΑ/ELECTRIC OVERBLANKET

MODEL NO.:

PROB-81085

220-240V 50Hz, 130W

Παρακαλούμε διαβάστε προσεκτικά όλες τις οδηγίες χρήσης πριν την χρήση της συσκευής και φυλάξτε τις για πιθανή μελλοντική χρήση.

Please read all instructions carefully before using the product and keep it for possible future reference.

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

Διαβάστε προσεκτικά τις οδηγίες χρήσης πριν θέσετε τη συσκευή σε λειτουργία και φυλάξτε τις οδηγίες και την απόδειξη αγοράς.

Διαστάσεις :

Ηλεκτρική κουβέρτα 160x130 εκατοστά συνοδεύετε από 1 χειριστήριο 130W

ΟΔΗΓΙΕΣ ΑΣΦΑΛΕΙΑΣ

Η μη τήρηση των ακολούθων υποδείξεων μπορεί να προκαλέσει σωματικές βλάβες ή υλικές ζημιές (ηλεκτροπληξία, εγκαύματα στο δέρμα, πυρκαγιά). Οι ακόλουθες υποδείξεις ασφάλειας και κινδύνων δεν χρησιμεύουν μόνο για την προστασία της υγείας σας ή και τρίτων προσώπων αλλά και την προστασία του ίδιου του προϊόντος. Τηρείτε για αυτό τις υποδείξεις ασφαλείας και παραδίδετε αυτές τις οδηγίες σε τρίτους σε περίπτωση που δώσετε το προϊόν για χρήση.

1. Μη χρησιμοποιείτε τη συσκευή για κανένα άλλο σκοπό εκτός από αυτόν που περιγράφεται στο παρόν εγχειρίδιο χρήσης.
2. Μη χρησιμοποιείτε τη συσκευή σε εξωτερικούς χώρους.
3. Η συσκευή προορίζεται αποκλειστικά για ιδιωτική, οικιακή χρήση και για τον προβλεπόμενο σκοπό.
4. Βεβαιωθείτε ότι η τάση του δικτύου σας είναι η ίδια με την τάση που αναγράφεται στην ετικέτα της συσκευής.
5. Χρησιμοποιείτε τη συσκευή μόνο σε γειωμένη και σωστά εγκατεστημένη πρίζα.
6. Μη χρησιμοποιείτε επέκταση καλωδίου.
7. Μη χρησιμοποιείτε το επίστρωμα διπλωμένο.
8. Μη χρησιμοποιείτε το επίστρωμα τσαλακωμένο.
9. Μην τρυπάτε με καρφίτσες και αιχμηρά αντικείμενα τη συσκευή.
10. Μη λειτουργείτε και μη τοποθετείτε τη συσκευή σε μέρη με υγρασία ή σε σημεία που μπορεί να βρέχεται.
11. Μη βυθίζετε τη συσκευή, το καλώδιο του ρεύματος ή το φις σε νερό ή άλλο υγρό.
12. Μη εκθέτεται το υπόστρωμα σε άμεσο ηλιακό φως και μη το σιδερώνετε.
13. Μη χρησιμοποιείτε τη συσκευή με βρεγμένα χέρια. Εάν η συσκευή έχει βραχεί αποσυνδέστε την αμέσως από την πρίζα.
14. Το επίστρωμα να μη χρησιμοποιείται από άτομα χρήζοντα βοήθειας, βρέφη ή άτομα ευαίσθητα στη θερμότητα.
15. Χρησιμοποιείτε τη συσκευή μόνο ως επίστρωμα.
16. Η συσκευή δεν προορίζεται για ιατρική χρήση.
17. Μη χρησιμοποιείτε το επίστρωμα όταν υπάρχουν βαριά αντικείμενα πάνω σε αυτό.

18. Μη καθαρίζετε το επίστρωμα με στεγνό καθάρισμα .
19. Χρησιμοποιείτε το επίστρωμα μόνο με το χειριστήριο που παρέχετε με το προϊόν.
20. Μη τοποθετείτε πάνω στη συσκευή ρούχα για να στεγνώσουν .
21. Μη χρησιμοποιείτε τη συσκευή μαζί με άλλες συσκευές θέρμανσης.
22. Μη τσαλακώνετε το επίστρωμα.
23. Μη μετακινείτε τη συσκευή όταν είναι σε λειτουργία.
24. Βεβαιωθείτε ότι το καλώδιο της συσκευής δεν έρχεται σε επαφή με ζεστά μέρη της συσκευής.
25. Μην αφήνετε τη συσκευή να λειτουργεί χωρίς επίβλεψη.
26. Αποσυνδέετε τη συσκευή από το ρεύμα μετά τη χρήση.
27. Ελέγχετε κατά διαστήματα τη συσκευή και το καλώδιο για τυχόν φθορές.
28. Μην τραβάτε ή τεντώνετε το καλώδιο.
29. Για να αποφύγετε τον κίνδυνο ηλεκτροπληξίας , μη βυθίζετε το καλώδιο, το φις η τη συσκευή σε νερό ή άλλο υγρό.
30. Απαγορεύετε η χρήση της συσκευής από παιδιά .
31. Μην επιτρέπτε στα παιδιά να παίζουν με τα υλικά συσκευασίας.

Τεχνικά χαρακτηριστικά

	Ηλ. Κουβέρτα	
Μέγεθος	160X130cm	
Τάση	220V	
Ισχύς	130W	
Συχνότητα	50Hz	

ΛΕΙΤΟΥΡΓΙΑ ΗΛΕΚΤΡΙΚΗΣ ΚΟΥΒΕΡΤΑΣ

Αρχική χρήση

Συνδέστε πρώτα το χειριστήριο στην θερμαινόμενη κουβέρτα εισάγοντας το βύσμα- σύνδεσμο.

Στη συνέχεια, το κύριο βύσμα στην πρίζα.

Η πλευρά ελέγχου είναι η περιοχή του κεφαλιού.

Ενεργοποίηση

Για να ενεργοποιήσετε τη θερμαινόμενη κουβέρτα, πατήστε το κουμπί ON/OFF και τη ρύθμιση θερμοκρασίας στο επίπεδο 1,2,3,4,5 ή 6

Οδηγίες Λειτουργίας - Ηλεκτρονικός ελεγκτής

1. Πατήστε το κουμπί **On/Off**, ενεργοποιήστε ή απενεργοποιήστε την ηλεκτρική κουβέρτα

2. Πατήστε το κουμπί "Θερμοκρασία" "**Temp**", και επιλέξτε ένδειξη ρύθμισης θέρμανσης από 1,2,3,4,5 έως 6

3. Πατήστε το "κουμπί ώρας"**Timer**", και επιλέξτε ρύθμιση χρονοδιακόπτη ώρας από 1,2,3,4,5,6,7,8,9,10,11,12. Το 1 είναι για 1 ώρα και το 12 είναι για 12 ώρες.

Πατήστε το κουμπί "CANCEL", επιστρέψτε στην κατάσταση απενεργοποίησης είναι επίπεδο 3, ο χρόνος είναι 3 ώρες

ΠΡΟΣΟΧΗ: Να κλείνετε πάντα το προϊόν και να αποσυνδέετε το καλώδιο τροφοδοσίας από την πρίζα όταν δεν το χρησιμοποιείτε.

Ρύθμιση της θερμοκρασίας

Επίπεδο 1: Ελάχιστη θερμότητα

Επίπεδο 2-5: ατομική θέρμανση

Επίπεδο 6: Μέγιστη θέρμανση

Ο γρήγορος τρόπος για να ζεσταθεί η θερμαινόμενη κουβέρτα είναι να ρυθμίσετε αρχικά την υψηλότερη ρύθμιση θερμοκρασίας.

Εάν η θερμαινόμενη κουβέρτα χρησιμοποιείται για αρκετές ώρες, σας προτείνουμε να ρυθμίσετε τη χαμηλότερη ρύθμιση θερμοκρασίας στο χειριστήριο για να αποφύγετε την υπερθέρμανση του σώματος και, συνεπώς, τυχόν εγκαύματα στο δέρμα ή θερμοπληξία.

Αυτόματη απενεργοποίηση

Η κουβέρτα έχει ρυθμίσεις χρονοδιακόπτη 12 ωρών. Από 1 ώρα έως 12 ώρες και έπειτα ανάλογα με το χρόνο που έχετε επιλέξει σβήνει αυτόματα.



	ΠΛΥΝΕΤΕ ΣΤΟ ΠΛΥΝΤΗΡΙΟ στους 30°C		Πλύνετε στο χέρι
	Μη χρησιμοποιείτε λευκαντικό		Όχι στεγνό καθάρισμα
	Δε μπαίνει στο στεγνωτήριο		Φυσικό στέγνωμα υπό σκιά Μη χρησιμοποιείτε μανταλάκια
	Μη σιδερώνετε		Μην τρυπάτε το υπόστρωμα με καρφίτσες, παραμάνες ή αιχμηρά αντικείμενα

Δ. ΚΑΘΑΡΙΣΜΟΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗ

Η ηλεκτρική κουβέρτα μπορεί να πλυθεί στο πλυντήριο ρούχων. Ωστόσο με το πλύσιμο στο χέρι θα παρατείνετε τη διάρκεια ζωής του επιστρώματος. Για πλύσιμο στο πλυντήριο ή στο χέρι αφαιρέστε το χειριστήριο και τοποθετήστε το επίστρωμα σε ειδική θήκη-δίχτυ πλυντηρίου και κλείστε την. Χρησιμοποιήστε μικρή ποσότητα απορρυπαντικού και ρυθμίστε το πλυντήριο σε πρόγραμμα για ευαίσθητα με μέγιστη θερμοκρασία 30C. Μετά το τέλος του πλυσίματος, αφαιρέστε το επίστρωμα από τη θήκη και απλώστε το για να στεγνώσει. Μη συνδέσετε το καλώδιο τροφοδοσίας στην ηλεκτρική κουβέρτα πριν στεγνώσει.

Μη χρησιμοποιείτε μανταλάκια.

ΑΠΟΘΗΚΕΥΣΗ

Αποθηκεύστε την ηλεκτρική κουβέρτα μόνο όταν είναι τελείως στεγνή. Μην το απλώνετε στον ήλιο και μη το σιδερώνετε για να στεγνώσει. Όταν η ηλεκτρική κουβέρτα στεγνώσει, διπλώστε τη χωρίς να δημιουργηθούν πτυχές. Μην χρησιμοποιείτε αντισκωρικά όπως ναφθαλίνη.



Το προϊόν αυτό είναι κατασκευασμένο σε πλήρη συμμόρφωση με τις ισχύουσες οδηγίες της Ευρωπαϊκής Ένωσης που διέπουν ηλεκτρικές συσκευές αυτού του τύπου.



Προστασία του περιβάλλοντος

Εάν κάποια μέρα διαπιστώσετε ότι η συσκευή σας χρειάζεται αντικατάσταση ή δεν σας χρησιμεύει πλέον, σκεφτείτε την προστασία του περιβάλλοντος:

- 1) Μην πετάξετε την συσκευή σας μαζί με τα υπόλοιπα αστικά απόβλητα (αυτή είναι και η σημασία του αναγραφόμενου συμβόλου ανακύκλωσης).
- 2) Απευθυνθείτε στην Δημοτική Αρχή σας για να σας υποδείξει τα σημεία διάθεσης της συσκευής σας για ανακύκλωση.
- 3) Διαθέτοντας την άχρηστη πλέον συσκευή σας στα σωστά σημεία ανακύκλωσης βοηθάτε στην προστασία του περιβάλλοντος καθώς και στην εκμετάλλευση εκ νέου των υλικών της συσκευής σας.
- 4) Οι ηλεκτρικές συσκευές λόγω των υλικών κατασκευής τους εάν δεν διατεθούν σωστά μπορεί να έχουν άσχημες επιπτώσεις στο περιβάλλον και κατ' επέκταση στην υγεία μας.

Με την εγγύηση της:



BUY WAY A.E.
Λεωφόρος Τυρταίου
31χλμ Αθηνών - Λαμίας
19014 Αφίδνες
Τηλ.: +30 210-2464214
www.buyway.gr

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTION

Read the operating instructions carefully before putting the appliance into operation and keep the instructions, the receipt and, if possible, the box with the internal packing. If you give this device to other people, please also pass on the operating instructions.

USER MANUAL SUMBOLS

Important information for your safety is specially marked. It is essential to comply with these instructions in order to avoid accidents and prevent damage to the machine:

WARNING: This sign warns you of dangers to your health and indicates possible injury risks,

CAUTION: This sign refers to possible hazards to the machine or others objects.

NOTE: This sign highlights tips and information

SAFETY INSTRUCTIONS

1. Do not use the appliance for any purpose other than that described in this user manual.
2. The appliance is designed exclusively for private, domestic use and for the envisaged purpose.
3. Do not use the appliance outdoors
4. Check that the voltage indicated on the appliance rating label corresponds to the voltage in the mains.
5. Always plug the appliance into an outlet that is earthed. Risk of electric shock!
6. Do not use an extension cable
7. Do not operate or place the appliance in damp places or in areas where it may get wet. Do not immerse the appliance, power cord or plug in water or any other liquid.
8. Do not expose the electrical substrate to direct sunlight and do not iron it.
9. Do not use the substrate folded
10. Do not use the substrate drumpled
11. Do not pierce the appliance with pins, latches or sharp objects. Do not attach or metal objects to the appliance.
12. Do not use the appliance if it is wet.
13. Do not use the appliance with wet hands. If the appliance is wet, unplug it immediately.
14. Use the appliance only as a substrate. Do not whap around the appliance or use it as a blanket
15. Do not use the substrate by persons in need of assistance, infants or persons sensitive to heat
16. This appliance is not intended for medical use.

17. Do not use the substrate on a bed with adjustable tilt, or if you do use it, make sure that the substrate or cord cannot be folded or rucked.
18. Do not use the substrate when there are heavy objects on it so as not to overheat the appliance
19. Use only with the control supplied with the substrate
20. Do not dry clean the substrate
21. Do not place fabrics/clothes on the appliance to dry or for any other reason.
22. Do not use the appliance together with other heating appliances
23. Do not wrinkle the substrate.
24. Make sure the thermostat is fully and correctly positioned on the substrate.
Risk of electric shock or fire
25. Do not move the appliance while it is in operation
26. Make sure that the power cord does not come into contact with hot parts of the appliance or come into contact with sharp corners
27. Do not let the power cord hang from the edge of the bed or out of the reach of children
28. Do not allow the power to touch any hot surface
29. Make sure the power cord is not pressed or wedged by any object. Never step on the power cord and never place it under carpets or mats where there is a risk of stepping on it. Hold the power cord where there is no risk of tripping.
30. When storing the appliance, switch the appliance off and always pull the plug out of the socket(pull the plug itself, not the lead).
31. Do not operate the appliance without supervision. If you should leave the workplace, always unplug the appliance
32. Always unplug the appliance after usage(pull the plug itself, not the lead).
33. Periodically check the appliance and the cable for damage. Do not operate the appliance with a damaged cord. In order to avoid the risk of an electric shock, never try to repair the appliance by yourself. Bring it to the authorized service station for repair, use only the original spare parts.
34. Do not pull or stretch the power cable.
35. To protect against risk of electric shock, do not immerse the cord, plug or unit in water or any other liquid.
36. Take special care when using the appliance in places where there are children, the disabled or people with reduced physical, sensory or mental abilities.
37. This appliance may be used by persons with limited physical, sensory or mental abilities or by persons without experience and knowledge, provided that they use it under supervision or have been instructed concerning use of the appliance in a safe way and understand the risks involved.
38. The use of the appliance by children is prohibited.
39. Do not use the appliance for pets.
40. Keep the appliance and its cord out of the reach of children, babies and pets.
41. In order to ensure our children's safety, please keep all packaging(plastic

bags, boxes ,polystyrene etc.) out of their reach. Do not allow children to play with the foil. Danger of suffocation!

42. If the appliance is used inappropriately or for professional or semi-professional purposes or if it is not used according to the instructions of the user manual, the warranty becomes invalid and SUN SA refuses any liability for damage caused.

TECHNICAL SPECIFICATIONS

	Electric blanket	
Sizes	160X130cm	
Rating	220V	
Power	130W	
Frequency	50Hz	

OPERATION OF THE ELECTRIC BLANKET

Initial use

First connect the control to the heated over blanket by inserting the plug-in coupling.

Then the main plug into the socket.

The side of control is head area.

Switching ON

To switch on the heated over blanket set the slider for ON/OFF and temperature setting to setting 1,2,3,4,5or6

Operating Instructions - Electronic controller

1.Press **On/Off** button , switch on or off the electric blanket

2.Press "**Temp**" button , the heating setting indicator as 1,2,3,4,5or6

3.Press "**Time**" button" , the time setting indicator indicator circulates from 1,2,3,4,5,6,7,8,9,10,11,12 . 1 is for 1 hour and 12 is for 12 hours.

Press "**CANCEL**" buton , return to the default state is level 3,time is 3 hours

CAUTION : Always turn of the product and disconnect the power cord from the outlet when not in use.

Setting the temperature

Level1: Minimum heat

Level2-5: individula heating

Level6: Maximum heating

The fast way to warm up the heated over blanket is to initially set the highest temperature setting.

If the heated over blanket is being used over several hours, we recomended that you set the lowest temperature setting on the control to avoid the body overheating and thereby any potential burns to the skin or heat stroke.

Automatic switch off









The blanket has 12 hours timing settings. 1/2/3/4/5/6/7/8/9/10/11/12 auto off



CLEANING AND MAINTENANCE

Machine washing of the electric blanket is possible; however, hand washing will prolong the life of the underblanket. To machine wash, remove the controller and place the electric blanket in a bag and seal it. Use a small amount of detergent and set the washing machine to a " Sensitive Wash" program with maximum temperature of 30C. When washed, remove the underblanket from the bag and drape it over a clothes line to dry. Do not use clothes pegs to secure it.

Care and cleaning

	Machine wash at 30		Wash by hand
	Do not use bleach		Do not dry clean
	Does not go in the dryer		Natural drying in the shade. Do not use clothespins
	Do not iron		Do not puncture the substrate with sharp objects

STORAGE

1. Store electric heated substrate only if it dry, it should be hanged at a ventilated location to dry naturally.
2. Do not connect the underblanket to power supply in order to dry it
3. So not expose it to the sun and do not iron it to dry. This will cause safety problems due to damage to the insulation.
4. The dry electric heated substrate should be folded without any crease
5. Do not place it under quit or other things in order to avoid any pressure
6. Do not use mothproofing agent like naphthalene which will damage the insulation material.



This product is in strict conformity with all the valid directives of European Union applying on this type of electrical appliances.



Protecting the environment

Should you find one day that your appliance needs to be replaced or if it is of no further use to you, think of the protection of the environment:

- 1) Do not dispose your appliance along with the rest of the public waste (this is also the meaning of the shown recycling sign).
- 2) Contact your Public Authorities and they will instruct you of the recycling centers to which your appliances must be disposed.
- 3) Correct disposal of your appliance helps the protection of the environment as well as the recycling of the appliance components.
- 4) The electrical appliances due to their construction materials, if not correctly disposed, may lead to environmental and furthermore health hazards.

With the warranty of:



BUY WAY S.A.
Tyrtaiou Avenue
31km Athens - Lamias
Tel.: +30 210-2464214
www.buyway.gr