



## ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

**Επιτραπέζιο αναλογικό ρολόι με αθόρυβη λειτουργία  
Μοντέλο 2810**

**Λειτουργεί με μπαταρία 1 X 1.5V τύπου AA**

**Παρακαλούμε διαβάστε προσεκτικά όλες τις οδηγίες χρήσης πριν την χρήση της συσκευής και φυλάξτε τις για πιθανή μελλοντική χρήση.**

### Τοποθέτηση μπαταρίας

Ανοίξτε το καπάκι της θήκης μπαταριών και εισάγετε μία μπαταρία 1XAA 1.5V. Παρακαλούμε εισάγετε τη μπαταρία με τη σωστή πολικότητα ακολουθώντας τις αντίστοιχες ενδείξεις στο εσωτερικό της θήκης μπαταρίας ώστε να αποφύγετε τυχόν δυσλειτουργία ή βλάβη στο μηχανισμό της συσκευής.

### Ρύθμιση ώρας

Γυρίστε το διακόπτη ρύθμισης ώρας (διακόπτης με τους δείκτες ρολογιού) που βρίσκεται στο πίσω μέρος της συσκευής περιστρέφοντάς τον προς την κατεύθυνση που σας δείχνει το βελάκι μέχρι οι δείκτες να φτάσουν στη σωστή ώρα.

### Ρύθμιση ξυπνητηριού

Γυρίστε το διακόπτη ρύθμισης ξυπνητηριού (διακόπτης με το καμπανάκι) που βρίσκεται στο πίσω μέρος της συσκευής περιστρέφοντάς τον προς την κατεύθυνση που σας δείχνει το βελάκι μέχρι να φτάσετε στην ώρα στην οποία θέλετε να χτυπήσει το ξυπνητήρι σας. Για να θέσετε το ξυπνητήρι σε λειτουργία, γυρίστε το διακόπτη λειτουργίας του ON/OFF που βρίσκεται στο πλάι της συσκευής στη θέση ON.

### Λειτουργία αναβολής SNOOZE

Όταν το ξυπνητήρι σας χτυπήσει μπορείτε να χρησιμοποιήσετε τη λειτουργία αναβολής (snooze) πατώντας το διακόπτη SNOOZE/LIGHT που βρίσκεται στο επάνω μέρος της συσκευής. Το ξυπνητήρι θα σταματήσει αλλά θα ξαναχτυπήσει μετά την πάροδο 4 λεπτών (λειτουργία αναβολής).

Για να κλείσετε τελείως το ξυπνητήρι σας, γυρίστε το διακόπτη ON/OFF στο πλάι της συσκευής στη θέση OFF.

Παρακαλούμε σημειώστε ότι στην περίπτωση που αφήσετε το ξυπνητήρι σας να χτυπάει, η συχνότητα των ήχων θα αυξάνεται σταδιακά μέχρι να γίνει ένας συνεχής επαναλαμβανόμενος ήχος (μπιπ-μπιπ).

### Λειτουργία φωτισμού LED

Κατά τη διάρκεια της νύχτας, αν θέλετε να φωτίσετε το καντράν του ρολογιού σας για να δείτε την ώρα, πατήστε το διακόπτη SNOOZE/LIGHT στην κορυφή της συσκευής και κρατήστε το πατημένο για όσο θέλετε το καντράν σας να φωτίζεται. Όλο το καντράν σας θα φωτιστεί με τον ειδικό φωτισμό LED που είναι ενσωματωμένος στη συσκευή.

### Προσοχή:

- Μην τοποθετείτε το ρολόι σας σε μέρη όπου:
  - Υπάρχει υγρασία, σκόνη ή μέρη που έχουν διαβρωτικά αέρια.
  - Υπάρχουν ισχυρές δονήσεις
- Μην χρησιμοποιείτε διαλυτικά μπιογιάς ή άλλα διαλυτικά ή διαβρωτικά καθαριστικά για να καθαρίσετε το σώμα της συσκευής.
- Αν δε θέλετε να χρησιμοποιήσετε το ρολόι σας για μεγάλο χρονικό διάστημα, παρακαλούμε αφαιρέστε τη μπαταρία από τη συσκευή.
- Ποτέ μην υποβάλλετε τη συσκευή σας σε τραντάγματα ή χτυπήματα και μην την αφήνετε να πέσει κάτω καθώς κάτι τέτοιο μπορεί να προκαλέσει ανεπανόρθωτη ζημιά στη συσκευή σας.



Το προϊόν αυτό είναι κατασκευασμένο σε πλήρη συμμόρφωση με τις ισχύουσες οδηγίες της Ευρωπαϊκής Ένωσης που διέπουν συσκευές αυτού του τύπου.

### Προστασία του περιβάλλοντος

Εάν κάποια μέρα διαπιστώσετε ότι η συσκευή σας χρειάζεται αντικατάσταση ή δεν σας χρησιμεύει πλέον, σκεφτείτε την προστασία του περιβάλλοντος:

- Μην πετάξετε την συσκευή σας μαζί με τα υπόλοιπα αστικά απόβλητα (αυτή είναι και η σημασία του αναγραφόμενου συμβόλου ανακύκλωσης).
- Απευθυνθείτε στην Δημοτική Αρχή σας για να σας υποδείξει τα σημεία διάθεσης της συσκευής σας για ανακύκλωση.
- Διαθέτοντας την άχρηστη πλέον συσκευή σας στα σωστά σημεία ανακύκλωσης βοηθήστε στην προστασία του περιβάλλοντος καθώς και στην εκμετάλλευση εκ νέου των υλικών της συσκευής σας.
- Οι ηλεκτρικές συσκευές λόγω των υλικών κατασκευής τους εάν δεν διατεθούν σωστά μπορεί να έχουν άσχημες επιπτώσεις στο περιβάλλον και κατ' επέκταση στην υγεία μας.

Με την εγγύηση της:



BUY WAY A.E.  
Λεωφόρος Τυρταίου,  
31<sup>ο</sup> χλμ Αθηνών-Λαμίας,  
19014 Αφίδνες, Ελλάδα  
Τηλ.: +30 210-2464214  
[www.buyway.gr](http://www.buyway.gr)



# ALFA ONE

## USE INSTRUCTIONS

### Table analog clock with sweep movement (silent operation) Model 2810

Operates with a battery 1 X 1.5V type AA

Please read all instructions carefully before using the product and keep it for possible future reference.

#### Battery assembly

Open the battery compartment cover and insert 1XAA 1.5V battery. The polarity of AA battery must be inserted as indicated in the battery compartment to prevent the movement mechanism from malfunction or damage.

#### Time setting

Turn the time setting round knob (knob with the clock hands sign) which is located on the back side of the device by rotating it towards the direction shown by the arrow until the clock hands reach the correct time.

#### Alarm setting

Turn the alarm setting round knob (knob with the bell sign) which is located on the back of the device by rotating it towards the direction shown by the arrow until the alarm hand reaches the alarm time you wish to set. To activate the alarm, press the alarm ON/OFF switch which is located on the side of the device, to position ON.

#### SNOOZE function

When your alarm is beeping you can use the snooze function by pressing the SNOOZE/LIGHT button which is located on the top side of the device. The alarm will stop but it will ring again after 4 minutes (snooze function).

To turn your alarm completely off, turn the alarm ON/OFF switch on the side of the device to position OFF.

Please note that in the case you let your alarm beeping, the sounds rate will gradually be increasing until it becomes a rapidly repeated beeping sound (beep beep).

#### LED light function

During night time, if you wish to light up the display of your clock to see the time, press the SNOOZE/LIGHT button at the top of the device and keep it pressed for as long as you wish your display to light up. The whole display will be illuminated with the built in LED light of the device.

#### Attention:

1. Never place your clock in areas with:
  - Moist, dust or in places with corrosive gas
  - Strong vibrations
2. Never use paint thinners or dissolvent or any other corrosive cleanser to clean the body of your device.
3. If you do not wish to use your clock for a long period of time, please remove the battery from its battery compartment.
4. Never shake or hit your device or let it fall down as such actions may cause irreparable damage to the device.



This product is in strict conformity with all the valid directives of European Union applying on this type of appliances.

#### Protecting the environment

Should you find one day that your appliance needs to be replaced or if it is of no further use to you, think of the protection of the environment:

- 1) Do not dispose your appliance along with the rest of the public waste (this is also the meaning of the shown recycling sign).
- 2) Contact your Public Authorities and they will instruct you of the recycling centers to which your appliances must be disposed.
- 3) Correct disposal of your appliance helps the protection of the environment as well as the recycling of the appliance components.
- 4) The electrical appliances due to their construction materials, if not correctly disposed, may lead to environmental and furthermore health hazards.

With the warranty of:

 Buy Way

BUY WAY S.A.  
Tyrtaiou Avenue,  
31<sup>st</sup> km Athinon-Lamias,  
19014 Afidnes, Greece  
Tel.: +30 210-2464214  
[www.buyway.gr](http://www.buyway.gr)