



ALFA ONE

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

**Επιτραπέζιο αναλογικό ρολόι με αθόρυβη λειτουργία
Μοντέλο AM03
Λειτουργεί με μπαταρία 1 X 1.5V τύπου AA**

**Παρακαλούμε διαβάστε προσεκτικά όλες τις οδηγίες χρήσης
πριν την χρήση της συσκευής και φυλάξτε τις για πιθανή
μελλοντική χρήση.**

Τοποθέτηση μπαταρίας

Ανοίξτε το καπάκι της θήκης μπαταριών και εισάγετε μία μπαταρία 1XAA 1.5V. Παρακαλούμε εισάγετε τη μπαταρία με τη σωστή πολικότητα ακολουθώντας τις αντίστοιχες ενδείξεις στο εσωτερικό της θήκης μπαταρίας ώστε να αποφύγετε τυχόν δυσλειτουργία ή βλάβη στο μηχανισμό της συσκευής.

Ρύθμιση ώρας

Γυρίστε το διακόπτη ρύθμισης ώρας (διακόπτης με τους δείκτες ρολογιού) που βρίσκεται στο πίσω μέρος της συσκευής περιστρέφοντάς τον προς την κατεύθυνση που σας δείχνει το βελάκι μέχρι οι δείκτες να φτάσουν στη σωστή ώρα.

Ρύθμιση Ξυπνητηριού

Γυρίστε το διακόπτη ρύθμισης Ξυπνητηριού (διακόπτης με το καμπανάκι) που βρίσκεται στο πίσω μέρος της συσκευής περιστρέφοντάς τον προς την κατεύθυνση που σας δείχνει το βελάκι μέχρι να φτάσετε στην ώρα στην οποία θέλετε να χτυπήσει το Ξυπνητήρι σας.

Για να θέσετε το Ξυπνητήρι σε λειτουργία, γυρίστε το διακόπτη λειτουργίας του ON/OFF που βρίσκεται στο πίσω μέρος της συσκευής στη θέση ON.

Για να κλείσετε το Ξυπνητήρι σας γυρίστε το διακόπτη του ON/OFF στη θέση OFF.

Προσοχή:

- Μην τοποθετείτε το ρολόι σας σε μέρη όπου:
 - Υπάρχει υγρασία, σκόνη ή μέρη που έχουν διαβρωτικά αέρια.
 - Υπάρχουν ισχυρές δονήσεις
- Μην χρησιμοποιείτε διαλυτικά μπογιάς ή άλλα διαλυτικά ή διαβρωτικά καθαριστικά για να καθαρίσετε το σώμα της συσκευής.
- Αν δε θέλετε να χρησιμοποιήσετε το ρολόι σας για μεγάλο χρονικό διάστημα, παρακαλούμε αφαιρέστε τη μπαταρία από τη συσκευή.
- Ποτέ μην υποβάλλετε τη συσκευή σας σε τραντάγματα ή χτυπήματα και μην την αφήνετε να πέσει κάτω καθώς κάτι τέτοιο μπορεί να προκαλέσει ανεπανόρθωτη ζημιά στη συσκευή σας.



Το προϊόν αυτό είναι κατασκευασμένο σε πλήρη συμμόρφωση με τις ισχύουσες οδηγίες της Ευρωπαϊκής Ένωσης που διέπουν συσκευές αυτού του τύπου.

Προστασία του περιβάλλοντος

Εάν κάποια μέρα διαπιστώσετε ότι η συσκευή σας χρειάζεται αντικατάσταση ή δεν σας χρησιμεύει πλέον, σκεφτείτε την προστασία του περιβάλλοντος:

- Μην πετάξετε την συσκευή σας μαζί με τα υπόλοιπα αστικά απόβλητα (αυτή είναι και η σημασία του αναγραφόμενου συμβόλου ανακύκλωσης).
- Απευθυνθείτε στην Δημοτική Αρχή σας για να σας υποδείξει τα σημεία διάθεσης της συσκευής σας για ανακύκλωση.
- Διαθέτοντας την άχρηστη πλέον συσκευή σας στα σωστά σημεία ανακύκλωσης βοηθήστε στην προστασία του περιβάλλοντος καθώς και στην εκμετάλλευση εκ νέου των υλικών της συσκευής σας.
- Οι ηλεκτρικές συσκευές λόγω των υλικών κατασκευής τους εάν δεν διατεθούν σωστά μπορεί να έχουν άσχημες επιπτώσεις στο περιβάλλον και κατ' επέκταση στην υγεία μας.

Με την εγγύηση της:

BUY WAY

BUY WAY A.E.
Λεωφόρος Τυρταίου,
31^ο χλμ Αθηνών-Λαμίας,
19014 Αφίδνες, Ελλάδα
Τηλ.: +30 210-2464214
www.buyway.gr



ALFA ONE

USE INSTRUCTIONS

**Table analog clock with sweep movement (silent operation)
Model AM03
Operates with a battery 1 X 1.5V type AA**

**Please read all instructions carefully before using the product
and keep it for possible future reference.**

Battery assembly

Open the battery compartment cover and insert 1XAA 1.5V battery. The polarity of AA battery must be inserted as indicated in the battery compartment to prevent the movement mechanism from malfunction or damage.

Time setting

Turn the time setting round knob (knob with the clock hands sign) which is located on the back side of the device by rotating it towards the direction shown by the arrow until the clock hands reach the correct time.

Alarm setting

Turn the alarm setting round knob (knob with the bell sign) which is located on the back of the device by rotating it towards the direction shown by the arrow until the alarm hand reaches the alarm time you wish to set.

To activate the alarm, press the alarm ON/OFF switch which is located on the back side of the device, to position ON. To turn your alarm off, turn the alarm ON/OFF switch to position OFF.

Attention:

1. Never place your clock in areas with:
 - Moist, dust or in places with corrosive gas
 - Strong vibrations
2. Never use paint thinners or dissolvent or any other corrosive cleanser to clean the body of your device.
3. If you do not wish to use your clock for a long period of time, please remove the battery from its battery compartment.
4. Never shake or hit your device or let it fall down as such actions may cause irreparable damage to the device.



This product is in strict conformity with all the valid directives of European Union applying on this type of appliances.

Protecting the environment

Should you find one day that your appliance needs to be replaced or if it is of no further use to you, think of the protection of the environment:

- 1) Do not dispose your appliance along with the rest of the public waste (this is also the meaning of the shown recycling sign).
- 2) Contact your Public Authorities and they will instruct you of the recycling centers to which your appliances must be disposed.
- 3) Correct disposal of your appliance helps the protection of the environment as well as the recycling of the appliance components.
- 4) The electrical appliances due to their construction materials, if not correctly disposed, may lead to environmental and furthermore health hazards.

With the warranty of:

 Buy Way

BUY WAY S.A.
Tyrtaiou Avenue,
31st km Athinon-Lamias,
19014 Afidnes, Greece
Tel.: +30 210-2464214
www.buyway.gr