

Primo®

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ USE INSTRUCTIONS



Ηλεκτρικό Επίστρωμα / Electric Blanket
MODEL NO.: PREB-81096 / PREB-81097
220V ~ 50Hz, 60W / 2x60W

Παρακαλούμε διαβάστε προσεκτικά όλες τις οδηγίες χρήσης πριν την χρήση της συσκευής και φυλάξτε τις για πιθανή μελλοντική χρήση.

Το προϊόν δεν είναι κατάλληλο για χρήση ως κύρια συσκευή θέρμανσης. Το προϊόν είναι κατάλληλο για χρήση σε καλά μονωμένους χώρους ή περιστασιακά

Please read all instructions carefully before using the product and keep it for possible future reference.

This product is not suitable for primary heating purposes. This product is only suitable for well insulated spaces or occasional use.

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ

Διαβάστε προσεκτικά τις οδηγίες χρήσης πριν θέσετε τη συσκευή σε λειτουργία και φυλάξτε τις οδηγίες και την απόδειξη αγοράς.

Διαστάσεις :

Μονό επίστρωμα 150x80 εκατοστά συνοδεύετε από 1 χειριστήριο 60W.

Διπλό επίστρωμα 160x140 εκατοστά συνοδεύετε από 2 χειριστήρια 60W το καθένα.

ΟΔΗΓΙΕΣ ΑΣΦΑΛΕΙΑΣ

Η μη τήρηση των ακολούθων υποδείξεων μπορεί να προκαλέσει σωματικές βλάβες ή υλικές ζημιές (ηλεκτροπληξία, εγκαύματα στο δέρμα, πυρκαγιά). Οι ακόλουθες υποδείξεις ασφάλειας και κινδύνων δεν χρησιμεύουν μόνο για την προστασία της υγείας σας ή και τρίτων προσώπων αλλά και την προστασία του ίδιου του προϊόντος. Τηρείτε για αυτό τις υποδείξεις ασφαλείας και παραδίδετε αυτές τις οδηγίες σε τρίτους σε περίπτωση που δώσετε το προϊόν για χρήση.

1. Μη χρησιμοποιείτε τη συσκευή για κανένα άλλο σκοπό εκτός από αυτόν που περιγράφεται στο παρόν εγχειρίδιο χρήσης.
2. Μη χρησιμοποιείτε τη συσκευή σε εξωτερικούς χώρους.
3. Η συσκευή προορίζεται αποκλειστικά για ιδιωτική, οικιακή χρήση και για τον προβλεπόμενο σκοπό.
4. Βεβαιωθείτε ότι η τάση του δικτύου σας είναι η ίδια με την τάση που αναγράφεται στην ετικέτα της συσκευής.
5. Χρησιμοποιείτε τη συσκευή μόνο σε γειωμένη και σωστά

εγκατεστημένη πρίζα.

6. Μη χρησιμοποιείτε επέκταση καλωδίου.
7. Μη χρησιμοποιείτε το επίστρωμα διπλωμένο.
8. Μη χρησιμοποιείτε το επίστρωμα τσαλακωμένο.
9. Μην τρυπάτε με καρφίτσες και αιχμηρά αντικείμενα τη συσκευή.
10. Μη λειτουργείτε και μη τοποθετείτε τη συσκευή σε μέρη με υγρασία ή σε σημεία που μπορεί να βρέχεται.
11. Μη βυθίζετε τη συσκευή, το καλώδιο του ρεύματος ή το φισ σε νερό ή άλλο υγρό.
12. Μην εκθέτεται το υπόστρωμα σε άμεσο ηλιακό φως και μη το σιδερώνετε.
13. Μη χρησιμοποιείτε τη συσκευή με βρεγμένα χέρια. Εάν η συσκευή έχει βραχεί αποσυνδέστε την αμέσως από την πρίζα.
14. Το επίστρωμα να μη χρησιμοποιείται από άτομα που χρήζουν βοήθειας, βρέφη ή άτομα ευαίσθητα στη θερμότητα.
15. Χρησιμοποιείτε τη συσκευή μόνο ως επίστρωμα.
16. Η συσκευή δεν προορίζεται για ιατρική χρήση.
17. Μη χρησιμοποιείτε το επίστρωμα όταν υπάρχουν βαριά αντικείμενα πάνω σε αυτό.
18. Μη καθαρίζετε το επίστρωμα με στεγνό καθάρισμα.
19. Χρησιμοποιείτε το επίστρωμα μόνο με το χειριστήριο που παρέχετε μαζί με το προϊόν.
20. Μη τοποθετείτε πάνω στη συσκευή ρούχα για να στεγνώσουν.
21. Μη χρησιμοποιείτε τη συσκευή μαζί με άλλες συσκευές θέρμανσης.
22. Μη τσαλακώνετε το επίστρωμα.
23. Μη μετακινείτε τη συσκευή όταν είναι σε λειτουργία.
24. Βεβαιωθείτε ότι το καλώδιο της συσκευής δεν έρχεται σε επαφή με ζεστά μέρη της συσκευής.
25. Μην αφήνετε τη συσκευή να λειτουργεί χωρίς επίβλεψη.
26. Αποσυνδέετε τη συσκευή από το ρεύμα μετά τη χρήση.

27. Ελέγχετε κατά διαστήματα τη συσκευή και το καλώδιο για τυχόν φθορές.

28. Μην τραβάτε ή τεντώνετε το καλώδιο.

29. Για να αποφύγετε τον κίνδυνο ηλεκτροπληξίας, μη βυθίζετε το καλώδιο, το φις ή τη συσκευή σε νερό ή άλλο υγρό.

30. Απαγορεύετε η χρήση της συσκευής από παιδιά.

31. Μην επιτρέπετε στα παιδιά να παίζουν με τα υλικά συσκευασίας.

Τεχνικά Χαρακτηριστικά

	Μονό	Διπλό
Μέγεθος	80X150cm	140X160cm
Τάση	220V	220V
Ισχύς	60W	2X60W
Συχνότητα	50Hz	50Hz

ΟΔΗΓΙΕΣ ΛΕΙΤΟΥΡΓΙΑΣ

Το ηλεκτρικό επίστρωμα θα πρέπει να τοποθετηθεί σε ένα σχετικά σκληρό, μη ρυθμιζόμενο σε κλίση στρώμα. Το επίστρωμα θα πρέπει να είναι τοποθετημένο ώστε να καλύπτει από τους ώμους έως τα πόδια σας.

Η πλευρά που είναι διακόπτης θα πρέπει να τοποθετείται κοντά στον ώμο για πιο βολική χρήση. Αφού απλώσετε το υπόστρωμα στο κρεβάτι πρέπει να τοποθετήσετε τους τέσσερις ιμάντες στις γωνίες του κρεβατιού για να μη μετακινείται ή τσαλακώνεται. Έπειτα καλύψτε το υπόστρωμα με ένα σεντόνι.

ΛΕΙΤΟΥΡΓΙΑ ΤΟΥ ΗΛΕΚΤΡΙΚΟΥ ΕΠΙΣΤΡΩΜΑΤΟΣ



Προθερμαίνετε το επίστρωμα για 30 λεπτά έως 1 ώρα πριν από τη χρήση.

Συνδέστε το τροφοδοτικό στην υποδοχή και βεβαιωθείτε ότι είναι συνδεδεμένα σταθερά. Επιλέξτε από το χειριστήριο το επιθυμητό επίπεδο θερμοκρασίας (3-υψηλή, 2-μεσαία, 1-χαμηλή). Αν ρυθμίσετε το διακόπτη στο υψηλό επίπεδο (3), το επίστρωμα θα ζεσταθεί σύντομα. Για χρήση κατά τη διάρκεια όλης της νύχτας, θα πρέπει να ρυθμίσετε το διακόπτη σε χαμηλό επίπεδο προκειμένου να αποφευχθεί ο κίνδυνος θερμοπληξίας.

Απενεργοποιήστε το επίστρωμα όταν δε χρειάζεστε θέρμανση. Η υποδοχή στο επίστρωμα πρέπει να αερίζεται. Μετά την χρήση απενεργοποιήστε το επίστρωμα και στη συνέχεια αποσυνδέστε το από την τροφοδοσία.

Το επίστρωμα μόλις το ενεργοποιήσετε ξεκινάει να δουλεύει στη υψηλότερη ταχύτητα(3) και έπειτα αφού πατήσετε το διακόπτη κατεβαίνει αντίστοιχα στο επίπεδο 2-1 και 0.

ΚΑΘΑΡΙΣΜΟΣ ΚΑΙ ΣΥΝΤΗΡΗΣΗ

Το επίστρωμα μπορεί να πλυθεί στο πλυντήριο ρούχων. Ωστόσο με το πλύσιμο στο χέρι θα παρατείνετε τη διάρκεια ζωής του επιστρώματος. Για πλύσιμο στο πλυντήριο αφαιρέστε το χειριστήριο και τοποθετήστε το επίστρωμα σε ειδική θήκη-δίχτυ πλυντηρίου και κλείστε την. Χρησιμοποιήστε μικρή ποσότητα απορρυπαντικού και ρυθμίστε το πλυντήριο σε πρόγραμμα για ευαίσθητα με μέγιστη θερμοκρασία 30C. Μετά το τέλος του

πλυσίματος, αφαιρέστε το επίστρωμα από τη θήκη και απλώστε το για να στεγνώσει. Μη συνδέσετε το καλώδιο τροφοδοσίας στο επίστρωμα πριν στεγνώσει. Μη χρησιμοποιείτε μανταλάκια.

ΑΠΟΘΗΚΕΥΣΗ

Αποθηκεύστε το επίστρωμα μόνο όταν είναι τελείως στεγνό.

Μην το απλώνετε στον ήλιο και μη το σιδερώνετε για να στεγνώσει. Όταν το επίστρωμα στεγνώσει, διπλώστε το χωρίς να δημιουργηθούν πτυχές.

Μην χρησιμοποιείτε αντισκωριακά όπως ναφθαλίνη.



Το προϊόν αυτό είναι κατασκευασμένο σε πλήρη συμμόρφωση με τις ισχύουσες οδηγίες της Ευρωπαϊκής Ένωσης που διέπουν ηλεκτρικές συσκευές αυτού του τύπου.



Οδηγίες για τη σωστή απόρριψη του προϊόντος σύμφωνα με την Ευρωπαϊκή Οδηγία 2002/96/ΕΚ

Εάν κάποια μέρα διαπιστώσετε ότι η συσκευή σας χρειάζεται αντικατάσταση ή δεν σας χρησιμεύει πλέον, σκεφτείτε την προστασία του περιβάλλοντος:

- 1) Μην πετάξετε την συσκευή σας μαζί με τα υπόλοιπα αστικά απόβλητα (αυτή είναι και η σημασία του αναγραφόμενου συμβόλου ανακύκλωσης).
- 2) Απευθυνθείτε στην Δημοτική Αρχή σας για να σας υποδείξει τα σημεία διάθεσης της συσκευής σας για ανακύκλωση.
- 3) Διαθέτοντας την άχρηστη πλέον συσκευή σας στα σωστά σημεία ανακύκλωσης βοηθάτε στην προστασία του περιβάλλοντος καθώς και στην εκμετάλλευση εκ νέου των υλικών της συσκευής σας.
- 4) Οι ηλεκτρικές συσκευές λόγω των υλικών κατασκευής τους εάν δεν διατεθούν σωστά μπορεί να έχουν άσχημες επιπτώσεις στο περιβάλλον και κατ' επέκταση στην υγεία μας.

Με την εγγύηση της:



BUY WAY A.E.
Λεωφόρος Τυρταίου,
31^ο χλμ. Αθηνών-Λαμίας,
19014 Αφίδνες, Ελλάδα
Τηλ.: +30 210-2464214
www.buyway.gr

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTION

Read the operating instructions carefully before putting the appliance into operation and keep the instructions, the receipt and, if possible, the box with the internal packing. If you give this device to other people, please also pass on the operating instructions.

SAFETY INSTRUCTIONS

1. Do not use the appliance for any purpose other than that described in this user manual.
2. The appliance is designed exclusively for private, domestic use and for the envisaged purpose.
3. Do not use the appliance outdoors
4. Check that the voltage indicated on the appliance rating label corresponds to the voltage in the mains.
5. Always plug the appliance into an outlet that is earthed. Risk of electric shock!
6. Do not use an extension cable
7. Do not operate or place the appliance in damp places or in areas where it may get wet. Do not immerse the appliance, power cord or plug in water or any other liquid.
8. Do not expose the electrical substrate to direct sunlight and do not iron it.
9. Do not use the substrate folded
10. Do not use the substrate drumpled
11. Do not pierce the appliance with pins, latches or sharp objects. Do not attach or metal objects to the appliance.
12. Do not use the appliance if it is wet.
13. Do not use the appliance with wet hands. If the appliance

- is wet, unplug it immediately.
14. Use the appliance only as a substrate. Do not whap around the appliance or use it as a blanket
 15. Do not use the substrate by persons in need of assistance, infants or persons sensitive to heat
 16. This appliance is not intended for medical use.
 17. Do not use the substrate on a bed with adjustable tilt, or if you do use it, make sure that the substrate or cord cannot be folded or rucked.
 18. Do not use the substrate when there are heavy objects on it so as not to overheat the appliance
 19. Use only with the control supplied with the substrate
 20. Do not dry clean the substrate
 21. Do not place fabrics/clothes on the appliance to dry or for any other reason.
 22. Do not use the appliance together with other heating appliances
 23. Do not wrinkle the substrate.
 24. Make sure the thermostat is fully and correctly positioned on the substrate. Risk of electric shock or fire
 25. Do not move the appliance while it is in operation
 26. Make sure that the power cord does not come into contact with hot parts of the appliance or come into contact with sharp corners
 27. Do not let the power cord hang from the edge of the bed or out pf the reach of children
 28. Do not allow the power to touch any hot surface
 29. Make sure the power cord is not pressed or wedged by any object. Never step on the power cord and never place it under carpets or mats where there is a risk of stepping on

- it. Hold the power cord where there is no risk of tripping.
30. When storing the appliance, switch the appliance off and always pull the plug out of the socket (pull the plug itself, not the lead).
 31. Do not operate the appliance without supervision. If you should leave the workplace, always unplug the appliance
 32. Always unplug the appliance after usage (pull the plug itself, not the lead).
 33. Periodically check the appliance and the cable for damage. Do not operate the appliance with a damaged cord. In order to avoid the risk of an electric shock, never try to repair the appliance by yourself. Bring it to the authorized service station for repair, use only the original spare parts.
 34. Do not pull or stretch the power cable.
 35. To protect against risk of electric shock, do not immerse the cord, plug or unit in water or any other liquid.
 36. Take special care when using the appliance in places where there are children, the disabled or people with reduced physical, sensory or mental abilities.
 37. This appliance may be used by persons with limited physical, sensory or mental abilities or by persons without experience and knowledge, provided that they use it under supervision or have been instructed concerning use of the appliance in a safe way and understand the risks involved.
 38. The use of the appliance by children is prohibited.
 39. Do not use the appliance for pets.
 40. Keep the appliance and its cord out of the reach of children, babies and pets.
 41. In order to ensure our children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach. Do not allow children to play with the foil.

Danger of suffocation!

42. If the appliance is used inappropriately or for professional or semi- professional purposes or if it is not used according to the instructions of the user manual, the warranty becomes invalid and SUN SA refuses any liability for damage caused.

TECHNICAL SPECIFICATIONS

	SINGLE SIZE	DOUBLE SIZE
Sizes	80X150cm	140X160cm
Rating	220V	220V
Power	60W	2X60W
Frequency	50Hz	50Hz

OPERATING INSTRUCTIONS

LAYING THE ELECTRIC HEATED UNDERBLANKET

The electrical heated substrate should be laid on a relatively hard and unadjustable mattress. The underblanket body should be laid flat from shoulder to feet while you are sleeping. The electric heated underblanket can be spread on the front or the back side. The side with the switch should be placed near the shoulder for the convenient operation. The four clasp on the corners should be fixed tightly to the mattress of the bed after you lay the electric heated underblanket to prevent that the underblanket from moving or creasing. (the creased parts tends to cause high temperature which is very dangerous).

In order to keep the electric heated underblanket flat, clean and to reduce the abrasion, please cover the underblanket with sheet

for use. (do not cover it with blanket or cotton fabric, which will prevent the underblanket from transmitting heat)

OPERATION OF THE ELECTRIC HEATED SUBSTRATE DURING USE



Please pre-heat the electric heating substrate for 30 minutes to 1 hour before using. Plug in the substrate to the power supply and make sure they are connected firmly. Select the proper temperature level(3- high, 2-middle, 1-low) by selector. Set the switch to high level and the substrate will warm up soon. For all night use the electric heated substrate, you should pre-set the switch to low level before sleeping in order to avoid the risk of heatstroke. Please switch off the substrate when you do not need heating.

The switch of the substrate should be exposed to the air. Do not cover it with quilt or pillow and please avoid pressure on it,

After use, please off the substrate and then unplug the appliance from the powersupply.

CLEANING AND MAINTENANCE

Machine washing of the underblanket is possible; however, hand washing will prolong the life of the underblanket. To machine wash, remove the controller and place the underblanket in a bag and seal it. Use a small amount of detergent and set the washing machine to a " Sensitive Wash" program with maximum temperature of 30C. When washed, remove the underblanket from the bag and drape it over a clothes line to dry. Do not use clothes pegs to secure it.

STORAGE

1. Store electric heated substrate only if it dry, it should be hanged at a ventilated location to dry naturally.
2. Do not connect the underblanket to power supply in order to dry it

3. So not expose it to the sun and do not iron it to dry. This will cause safety problems due to damage to the insulation.
4. The dry electric heated substrate should be folded without any crease
5. Do not place it under quit or other things in order to avoid any pressure
6. Do not use mothproofing agent like naphthalene which will damage the insulation material.



This product is in strict conformity with all the valid directives of European Union applying on this type of electrical appliances.

Instructions for the correct disposal of the unit according to European directive 2002/96/EU



Should you find one day that your appliance needs to be replaced or if it is of no further use to you, think of the protection of the environment:

- 1) Do not dispose your appliance along with the rest of the public waste (this is also the meaning of the shown recycling sign).
- 2) Contact your Public Authorities and they will instruct you of the recycling centers to which your appliances must be disposed.
- 3) Correct disposal of your appliance helps the protection of the environment as well as the recycling of the appliance components.
- 4) The electrical appliances due to their construction materials, if not correctly disposed, may lead to environmental and furthermore health hazards.

With the warranty of:



BUY WAY S.A.
Tyrtaiou Avenue,
31st km Athinon-Lamias,
19014 Afidnes, Greece
Tel.: +30 210-2464214
www.buyway.gr