

GREENTEK®

ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ USE INSTRUCTIONS



**ΚΕΡΑΙΑ ΕΞΩΤΕΡΙΚΟΥ ΧΩΡΟΥ FULL HD TV
ME ENΙΣΧΥΤΗ ΚΑΙ ΦΙΛΤΡΟ 4G/
OUTDOOR FULL HD TV ANTENNA WITH
AMPLIFIER AND 4G FILTER
ΜΟΝΤΕΛΟ/MODEL: HDO-F1**

**Παρακαλούμε διαβάστε προσεκτικά όλες τις οδηγίες
χρήσης πριν την χρήση της συσκευής και φυλάξτε τις για
πιθανή μελλοντική χρήση.**

**Please read all instructions carefully before using the
product and keep it for possible future reference.**

Παρακαλώ διαβάστε και φυλάξτε αυτές τις οδηγίες ασφαλείας

Διαβάστε προσεκτικά τις οδηγίες χρήσης πριν θέσετε τη συσκευή σε λειτουργία και φυλάξτε τις οδηγίες, την απόδειξη και εάν είναι δυνατόν το κουτί με την εσωτερική συσκευασία του προϊόντος.

Οδηγίες Ασφαλείας

1. Κρατήστε τη συσκευή μακριά από νερό.
2. Βεβαιωθείτε ότι το καλώδιο ρεύματος είναι εύκολα προσβάσιμο ανα πάσα στιγμή.
3. Για να αποφύγετε τον κίνδυνο ηλεκτροπληξίας, μη βυθίζετε το καλώδιο, το φις, το τροφοδοτικό ή τη συσκευή σε νερό ή οποιοδήποτε άλλο υγρό.
4. Βεβαιωθείτε ότι η τάση του δικτύου σας είναι η ίδια με την τάση που αναγράφεται στην ετικέτα της συσκευής.
5. Η συσκευή πρέπει να είναι πάντα απενεργοποιημένη πριν την συνδέσετε στην παροχή ρεύματος.
6. Κρατήστε το καλώδιο μακριά από θερμαινόμενες επιφανείες.
7. Μην αφήνετε τα παιδιά να παίζουν με τη συσκευή.
8. Για την ασφάλεια των παιδιών , κρατήστε μακριά όλα τα υλικά συσκευασίας.
9. Η συσκευή πρέπει να απενεργοποιείτε κατά τη διάρκεια καταιγίδων με κεραυνούς.

Εγκατάσταση

A. Τοποθέτηση στον ιστό




Τοποθετήστε το μπουλόνι U μέσω του ιστού, ρυθμίστε το στήριγμα της κεραίας και στερεώστε τις βίδες.



Δέσε περίπου 1 μέτρο του καλωδίου σήματος περιθώριο κάτω από την κεραία για να επιτρέπεται η περιστροφή της κεραίας.

Β. Επιτοίχια τοποθέτηση



Ανοίξτε τρύπες στον τοίχο ανάλογα με τη θέση των οπών στο στήριγμα της κεραίας, τοποθετήστε ούπα στις οπές, στερεώστε το στήριγμα στον τοίχο και στερεώστε με βίδες.

Γ. Τοποθέτηση σε κάγκελο



Τοποθετήστε το στήριγμα της κεραίας στο κιγκλίδωμα χρησιμοποιώντας το μπουλόνι U, προσαρμόστε τη βάση περιστροφής στο στήριγμα, κουμπώστε το καλώδιο σήματος και στερεώστε την κεραία στη βάση περιστροφής αφού ρυθμίσετε τη σωστή κατεύθυνση.


1. Στερέωση του αδιάβροχου καπακιού



Συνδέστε το καλώδιο σήματος στην υποδοχή εξόδου σήματος της κεραίας και ασφαλίστε το καλώδιο.

Στερεώστε το αδιάβροχο καπάκι που καλύπτει τις συνδέσεις για να αποφύγετε την είσοδο του νερού.


2. Σύνδεση και χρήση



Συνδέστε το καλώδιο σήματος από την κεραία στην υποδοχή εισόδου σήματος του τροφοδοτικού, συνδέστε την υποδοχή εξόδου τροφοδοσίας στον ψηφιακό δέκτη, συνδέστε το τροφοδοτικό με το τροφοδοτικό και συνδέστε το στην πρίζα και τέλος συνδέστε την τηλεόραση και τον ψηφιακό δέκτη.



Συνδέστε το καλώδιο σήματος από την κεραία στην υποδοχή εισόδου σήματος του τροφοδοτικού, συνδέστε την υποδοχή εξόδου τροφοδοτικού στην τηλεόραση, συνδέστε το τροφοδοτικό με το τροφοδοτικό και συνδέστε την στην πρίζα.



Συνδέστε το καλώδιο σήματος από την κεραία στον ψηφιακό δέκτη, ρυθμίστε τον δέκτη να παρέχει ρεύμα στην κεραία και συνδέστε την τηλεόραση και τον ψηφιακό δέκτη.

3. Πώς να βελτιώσετε την ποιότητα λήψης



Τοποθετήστε την κεραία έτσι ώστε να δείχνει προς τον πομπό και κρατήστε την ασφαλή απόσταση από μεταλλικά αντικείμενα, ηλεκτρικό εξοπλισμό και εμπόδια που μπορεί να περιορίσουν την επιθυμητή λήψη.

Περιστρέψτε την κεραία μέχρι να επιτευχθεί η βέλτιστη λήψη.

Ρυθμίστε τη θέση της κεραίας σύμφωνα με τη μετάδοση οριζοντίων ή κατακόρυφων σημάτων.

Τεχνικά χαρακτηριστικά:

Τάση λειτουργίας: AC 100-240V DC 5V/ 550mA

-Λήψη DVB-T/T2 T-Terrestrial, τηλεόραση Full HD, τοπικά ψηφιακά σήματα UHF.

-Εύρος συχνοτήτων: VHF 174~230MHz UHF 470~790MHz

-Μέσο κέρδος: VHF:6,97dB UHF:20,74dB

-Ενσωματωμένα φίλτρα 4G/LTE

- Αντίσταση: 75Ω

-Απόσταση ρεσεψιόν: έως 50χλμ

Τροφοδοσία

Τροφοδοτείται από τον παρεχόμενο προσαρμογέα AC/DC

Μετασχηματιστής AC/DC:

Είσοδος: 100~240V~50/60Hz,0,2A

Έξοδος: 5V/550mA 2,75W

Συμπεριλαμβάνεται αξεσουάρ:

1×Αδιάβροχο καπάκι

Υποδοχή 1×F

1×Μεταλλικά κιτ τοποθέτησης

1×Πλαστικό κιτ τοποθέτησης

1×Μετασχηματιστής ρεύματος

1×Κιβώτιο τροφοδοσίας

1×8,5m Καλώδιο



Το προϊόν αυτό είναι κατασκευασμένο σε πλήρη συμμόρφωση με τις ισχύουσες οδηγίες της Ευρωπαϊκής Ένωσης που διέπουν ηλεκτρικές συσκευές αυτού του τύπου.



Προστασία του περιβάλλοντος

Εάν κάποια μέρα διαπιστώσετε ότι η συσκευή σας χρειάζεται αντικατάσταση ή δεν σας χρησιμεύει πλέον, σκεφτείτε την προστασία του περιβάλλοντος:

- 1) Μην πετάξετε την συσκευή σας μαζί με τα υπόλοιπα αστικά απόβλητα (αυτή είναι και η σημασία του αναγραφόμενου συμβόλου ανακύκλωσης).
- 2) Απευθυνθείτε στην Δημοτική Αρχή σας για να σας υποδείξει τα σημεία διάθεσης της συσκευής σας για ανακύκλωση.
- 3) Διαθέτοντας την άχρηστη πλέον συσκευή σας στα σωστά σημεία ανακύκλωσης βοηθάτε στην προστασία του περιβάλλοντος καθώς και στην εκμετάλλευση εκ νέου των υλικών της συσκευής σας.
- 4) Οι ηλεκτρικές συσκευές λόγω των υλικών κατασκευής τους εάν δεν διατεθούν σωστά μπορεί να έχουν άσχημες επιπτώσεις στο περιβάλλον και κατ' επέκταση στην υγεία μας.

Με την εγγύηση της:

 Buy Way

BUY WAY A.E.
Λεωφόρος Τυρταίου
19014 Αφίδνες, Ελλάδα
Τηλ.: +30 210-2464214
www.buyway.gr

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS.

Read the operating instructions carefully before putting the appliance into operation and keep the instructions, the receipt and, if possible, the box with the internal packing. If you give this device to other people, please also pass on the operating instructions.

USER MANUAL SYMBOLS

Important information for your safety is specially marked. It is essential to comply with these instructions in order to avoid accidents and prevent damage to the machine:

⚠ WARNING: This sign warns you of dangers to your health and indicates possible injury risks.

⚠ CAUTION: This sign refers to possible hazards to the machine or other objects.

i NOTE: This sign highlights tips and information

SAFETY INSTRUCTIONS

1. Keep the appliance away from water and do not use it in a humid environment.
2. Make sure the power cord is easily accessible at all times.
3. Ensure that the voltage indicated on the appliance rating label corresponds to the voltage in the mains. The appliance must always be switched off before connecting it to the power supply.
4. To protect against risk of electric shock, do not immerse the cord, plug, the charger or unit in water or any other liquid.
5. Keep the cord away from heated surfaces and appliances (e.g. electric hobs).
6. Do not let children play with the appliance.
7. In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- ⚠ WARNING:** Do not allow children to play with the foil. Danger of suffocation!
8. Periodically check the cable for damage.
- ⚠ WARNING:** Do not operate the appliance with a damaged cord. In order to avoid the risk of an electric shock, never try to repair the appliance by yourself. Bring it to the authorized service station for repair.
9. The appliance must be switched off during thunderstorms.

A Adjustment to the Mast




Place U-bolt through the mast, adjust the antenna bracket and fasten screws.



Tie approx. 1 meter of the signal wire loosely to the fixing pole at approx. 0.5 m below the antenna to allow the antenna to rotate.

B. Wall Mounting



Drill holes in the wall according to the holes position on the antenna bracket, hammer

plastic anchors into the holes, attach bracket to the wall and secure with screws.

C. Railing Mounting (Balcony)



Install the antenna bracket to the railing using the U-bolt, adjust the rotation base to the bracket, clip the signal cable and fix the antenna onto the rotation base after adjusting to the right direction.

1. Fixing the Waterproof Cap




Connect the signal cable to the signal output jack of the antenna and secure cable.



Fix the waterproof cap covering the connections to avoid water filtration.


2. Connection and Usage



Connect the signal cable from the antenna to the signal input jack of the power supply, connect the power supply output jack to the digital receiver, plug the power adaptor with the power supply and connect to power socket, and finally join the TV and the digital receiver.



Connect the signal cable from the antenna to the signal input jack of the power supply, connect the power supply output jack to the TV, plug the power adaptor with the power supply and connect to power socket.



Connect the signal cable from the antenna to the digital receiver, set the receiver to offer power to the antenna and join the TV and the digital receiver.

3. Adjustment on Receiving Directions



Adjust the antenna position according to the broadcast of horizontal or vertical signals.

TECHNICAL SPECIFICATIONS

Working voltage: AC 100-240V DC 5V/ 550mA

-Receives DVB-T/T2 T-Terrestrial, Full HD television, local digital UHF signals;

-Frequency range: VHF 174~230MHz UHF 470~790MHz

-Average Gain: VHF:6.97dB UHF:20.74dB

-Built-in 4G/LTE filters

-Impedance: 75Ω

-Reception Distance: up to 50km

Powering

To be powered by included AC/DC adaptor

AC/DC Adapter:

Input: 100~240V~50/60Hz,0.2A

Output: 5V/550mA 2.75W

Accessory Included:

1×Waterproof cap

1×F connector

1×Metal Mounting kits

1×Plastic Mounting kit

1×Power Adapter

1×Power supply box

1× 8.5m Cable



This product is in strict conformity with all the valid directives of European Union applying on this type of electrical appliances.



Protecting the environment

Should you find one day that your appliance needs to be replaced or if it is of no further use to you, think of the protection of the environment:

- 1) Do not dispose your appliance along with the rest of the public waste (this is also the meaning of the shown recycling sign).
- 2) Contact your Public Authorities and they will instruct you of the recycling centers to which your appliances must be disposed.
- 3) Correct disposal of your appliance helps the protection of the environment as well as the recycling of the appliance components.
- 4) The electrical appliances due to their construction materials, if not correctly disposed, may lead to environmental and furthermore health hazards.

With the warranty of:

BUY WAY S.A.
Tyrtaiou Avenue
19014 Afidnes, Greece
Tel.: +30 210-2464214
www.buyway.gr